iFLYTEK

iFLYTEK Smart Recorder SR302 Pro Product Instruction

Product Overview



Product Configuration

Processor: 8 cores
Storage: 32GB
Screen: 2.0 inch
Battery: 2000mAh
Microphone: 2+4
Manufacturer: iFLYTEK Co.,Ltd.
Manufacturer's address: No. 666 Wangjiang West Road, Hefei High-Tech Development Zone

Product Accessories

Product instruction X1

Type-C data cable X1

This product is sold without a power adapter, please use a power adapter that has been awarded the CCC certificate and complies with the relevant standards

User guide

How to use the recording function

I. Enable/Save recording

1. Enable recording (Method 1): Turn on the machine with bright screen, press the red (Recording Key) at the bottom, and the screen lights up to enter the recording function, and click it again to save in the bright screen.

2. Enable recording (Method 2): Turn on the machine, click the recording card in the center of the screen to start recording, or use the [OK button] at the bottom of the screen to start recording.
3. Select the recording mode: Click the icon in the upper right corner of the Recording Card to enter the recording mode selection page.
4. Save recording: select [Pause] in the recording interface - [Finish] button to save.

II. Recording modes

1. Smart mode: Applicable to most scenarios.
2. Conference mode: Suitable for multi-person and long-distance meetings, with a pickup range of 5 meters.
3. Speech mode: Applicable for multi-person lectures or press conferences within 10 meters.
4. Interview mode: Applicable for one-on-one interviews or conversations within three people within 1 meter.

III. Recording quality

Standard: 16k 16bit
Extra long: 8k 16bit

IV. Recording length

The maximum length of a single recording is up to 4 hours and 55 minutes.
*The above data are all from laboratory tests, and the actual data are subject to the use data of users.

V. Recording formates

wav: Lossless compression format file.

How to use the transcription function

I. Real-time transcription preview

1. When the recording is activated, the recording interface starts real-time transcription preview, and the real-time transcription result can be saved.
2. Please note that the transcription text of screens does not interrupt the live transcription.
3. When Battery Saver is turned on, there is no real-time transcription preview to reduce power consumption, and the complete transcription result can be obtained in the file details after the recording is finished.

II. Recording re-transcription

1. Real-time transcription results are synchronized and saved after the recording is saved.
2. To re-transcribe recordings, select [My Files] - select the corresponding file to enter [Player] - click [Start Transcription] button for re-transcription.
3. In case of incomplete transcription, select [My Files] - select the corresponding file to enter [Player] - click [More] button in the upper right and then [Transcribe] for re-transcription.
4. Users can choose to add turn-off transcription in recording, extend the use time, and go to the player for transcription after the recording is finished.

III. Whether to support external recording import for transcription

External recording import for transcription is not supported.

How to export files to computer

I. Export files using a computer

1. Keep the recorder on.
2. Connect the recorder to the computer via USB to export files (For Mac computers, the Android File Transfer tool needs to be installed, download the plug-in at https://dl.google.com/dl/android/jumper/mtp/current/AndroidFileTransfer.dmg).
3. Unlock the recorder and select [Export files] in the request access pop-up.
4. View under the [Record_File] folder of the computer disk.
5. Copy the required files to export the files to the computer.

II. File export format

Audio: wav
Text: doc

How to manage recorder files

I. Edit files

1. Single file operation: Select [My Files] and slide the target file left for the following operations: Rename the file (only supported in Chinese system language), delete the file.

2. Batch/single file management: Click [My Files] and click the [Select] button in the upper right corner to perform the following operations: multi-select/single-select target files to perform batch/single deletion operations on files.

II. Playing recording files

1. After the recording file is saved, enter [My Files] to view it, and the files are displayed in the order of the creation time of the recording.
2. Click the target file to enter the playback page.

Web side

2. Copy the downloaded offline language pack to the upgrade disk of the recorder.

Upgrade disk

III. Update the offline language package

1. Upon completion of copying offline language packages, unplug the USB and enter [Settings] - [General Settings] - [Manage Language Package] - enter [Update Language Package] interface for update.

Web side

2. Copy the downloaded offline language pack to the upgrade disk of the recorder.

Upgrade disk

III. Update the offline language package

1. Upon completion of copying offline language packages, unplug the USB and enter [Settings] - [General Settings] - [Manage Language Package] - enter [Update Language Package] interface for update.

How to upgrade the system version

I. Connect the computer through USB

1. Connect the recorder to the computer through USB, and select "Upgrade".
2.Access the upgrade disk of the recorder in your computer (For Mac computers, the Android File Transfer tool needs to be installed, download the plug-in at : https://dl.google.com/dl/android/jumper/mtp/current/AndroidFileTransfer.dmg).

II. Download system update pack

1. Open the [System and Offline Language Pack Update] link in the upgrade disk of the recorder on the computer, enter the System & Offline Language Pack Update website and download the latest system version.
2. Copy the downloaded system version pack to the upgrade disk of the recorder.

Web side

III. Upgrade the system

1. After copying the system version package, pull out the USB and upgrade at [Settings] - [System Update].

System update

Disclaimer

The user understands and agrees that iFLYTEK shall not be responsible for the following matters or liabilities and the developer's losses in the event of any of the followings:
1. force majeure situations
2. hacker attacks, computer virus intrusions or attacks
3. the equipment purchased is not been damaged, paralyzed or are not functioning properly
4. technical adjustments in the telecommunications sector
5. temporary closure due to government control
6. losses caused by the fault of iFLYTEK
7. It is the joint responsibility of iFLYTEK and users to maintain the security and proper use of the software. iFLYTEK has implemented reasonable technical measures necessary to protect the security of users' terminal information and data in accordance with industry standards. However, users need to acknowledge and agree that iFLYTEK cannot provide any absolute security warranty.
8. iFLYTEK audits the user's recordings in accordance with this agreement or other service agreements and standards in the Software. The audit does not guarantee whether the recording itself or other content in it violates laws and regulations or infringes the rights of third parties. If the user's recording itself or other content in it violates laws and regulations or infringes the rights of third parties, the user shall be solely responsible for the liability, and iFLYTEK is exempted for any damage caused to iFLYTEK as a result.
9. The software may use third party software or technology (including the open source code and public domain code that may be used by the software, the "third party"), and iFLYTEK will display the relevant authorized if the software uses software or technology from a third party, iFLYTEK will display the relevant agreements and documents, which may be attached to this Agreement, packaged in specific forms or otherwise presented to you for reading, etc., in accordance with relevant regulations or agreements.They may be displayed in the form of "Software License Agreement", "Open Source Software Notice", "Privacy Policy" or otherwise.The above-mentioned agreements and documents presented in various forms shall form an integral part of this agreement and have the same legal effect as this agreement. Users shall comply with these agreements when using. If the user violates the above, may file a lawsuit, impose a fine or take other sanctions against the user to make him or her bear the legal liability independently. If necessary, iFLYTEK should provide assistance.
10. Recorder service policy, subject to official channels

Cautions

1. The operating system only supports official upgrades, please refer to the latest features. Users are responsible for any security risks and losses caused by brushing the third-party system, including but not limited to loss of information theft, automatic SMS sending, location, etc.)
2. There is risk of explosion if the product is replaced with the wrong type of battery
3. Please ensure that used batteries are disposed of in accordance with the relevant laws and regulations
4. The recorder is an offline product, the recordings and transcribed texts recorded by the user during use are stored in the hardware device by default, and the user is responsible for managing the data. iFLYTEK will not view or process any personal information of users stored in the device

Waste Recycling Tips

In order to better protect our planet, when the user no longer needs to use the product or the service life of the product ends, please comply with the relevant national laws and regulations on the recycling of waste electronic products and hand them over to local manufacturers with national certified recycling qualifications for recycling.

Safety Information

Before using and operating this device, read the following precautions to ensure an optimal device performance and avoid dangerous use or unauthorized operation.

- When charging, an adapter should be plugged into a socket nearby and easily accessible. Use approved power adapters and chargers.
- Keep this device and its accessories that may contain small components out of the reach of children. Otherwise, children may damage this device and its accessories by mistake, or swallow the small components, which may cause choking.
- Avoid using the device in dusty, damp, or dirty environments, or near sources of magnetic interference.
- Keep the battery away from fire, excessive heat, and direct sunlight. Do not place it on or in heating devices. Do not disassemble, modify, throw, or squeeze it. Do not damage the battery in any way. Do not let it fall, drop, or expose it to external force or pressure, as this may cause it to leak, overheat, catch fire, or even explode. Do not disassemble the battery by yourself — you may damage the battery, which could cause overheating, fire, and injuries.
- Avoid disassembling or modifying your device and its accessories. Unauthorized disassembly and modifications may result in voiding the factory warranty.

CE

2206101-SM1 V1.0